Electrical continuity


All products in MP-cable installations comply to applicable demands regarding electrical continuity over splices according to SS-EN 61537:2007.

Painted trays have paint-free ends as standard and thus satisfy the requirements set out in the table below. For cutting and joining painted trays you must manually create an electrical connection across the splice. Ideally by means of a screwed metal joint on a paint-free surface (paint removed).

SP Technical Research Institute of Sweden in Borås have made test measurements 500 mm on each side of the splice with the following result.

 $50 \text{ m}\Omega$

 $50 \text{ m}\Omega$



8